










# 分联打印机常用配件图示表

序号	名称	图示1	图示2
1	主板 (U/R)	 <p>Diagram 1 of the mainboard (U) showing the front panel connector and various components.</p>	 <p>Diagram 2 of the mainboard (R) showing the back panel connector and various components.</p>
2	机架 (U/R)	 <p>Diagram of the printer frame (U/R) showing the internal structure and components.</p>	
3	打印头	 <p>Diagram 1 of the print head (U) showing the front view and the part number 1A-80250.</p>	
4	电源板 (U/R)	 <p>Diagram 1 of the power board (U) showing the front view and various components.</p>	 <p>Diagram 2 of the power board (R) showing the back view and various components.</p>

5	上壳		
6	底壳		
7	控制面板电路板		
8	HP传感器		
9	油毡		
10	防尘盖		

11	PE传感器电路板		
12	出纸器		
13	色带架		
14	上/下切刀		
15	切刀控制板		
16	15V电源适配器		
17	分层塑料片		
18	卡纸传感器（一组）		

19	纸仓满传感器（一组）		
20	搓纸轮		
21	弹簧		
22	拖纸器导杆		
23	后部搓纸轮		
24	前部走纸辊		

25	右支架		
26	左机架		
27	进纸通道选择拨杆		
28	分层组件		
29	打印头线缆 (U/R)		

30	拖纸器右侧链齿		
31	拖纸器左侧链齿		